

T~HANDLE

<http://www.oklahomadesigntech.com/saftanchor.html>

PATENT PENDING



You have several options when it comes to installing the SAF-T-ANCHOR...

The 6 point socket is recommended for installation of the SAF-T-ANCHORS with the welded 2" nut.
 The T-Handle can be used to install the temporary or permanent anchors.

Socket	
3/4" Drive - 2" - 6 point impact socket for use with the welded eye nut	SPT-6
T-Handle - 24" Length - 3/4" Drive	THDL-24
T-Handle - 36" Length - 3/4" Drive	THDL-36
T-Handle - 48" Length - 3/4" Drive	THDL-48
Ratchet - 3/4" Drive	THDL-RCT

